


ASSEMBLY INSTRUCTIONS:

720375-26 TV CONSOLE



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

Attention : Veuillez Lire Toutes Les Instructions Avant De Commencer L'assemblage De Ce Produit. Les Pièces Sont Lourdes. Pour Éviter Toute Blessure Et Pour Vous Assurer Que Le Produit N'est Pas Endommagé Pendant L'assemblage, Nous Vous Recommandons De Faire Appel À Une Ou Plusieurs Autres Personnes.


Cuidado: Favor De Leer Todas Las Instrucciones Antes De Ensamblar Su Producto. Estas Piezas Son Pesadas. Para Prevenir Heridas Personales Y Asegurar Que Su Producto No Sea Dañado Mientras Es Ensamblado, Se Recomienda La Asistencia De Una O Más Personas.



TIME



OF PEOPLE




DIFFICULTY

Important: Use hand tools for assembly. Power tools can lead to over-tightening and damage.













ASSEMBLY INSTRUCTIONS:


720375-26 TV CONSOLE



720375-26 TV CONSOLE















Parts List

CODE	DESCRIPTION	QTY
1	Top Panel 	1 pc
2	Bottom Panel 	1 pc
3	Fixed Shelf 	1 pc
4	Left Inside Panel 	1 pc
5	Right Inside Panel 	1 pc
6	Left Panel 	1 pc
7	Right Panel 	1 pc
8	Back Panel 	1 pc
9	Left Side Door 	1 pc
10	Right Side Door 	1 pc
11	Center Door 	1 pc
12	Adjustable Shelf 	2 pcs






Assembly Tools Required (Not Included)

Hardware List


CODE	DESCRIPTION	QTY
A	Metal Frame 	1 pc
B	Metal Legs 	2 pcs
C	Hex-Head bolts 1/4"x35mm 	10 pcs
D	Allen Wrench 	1 pc
E	Hex-Head bolts 1/4"x60mm 	6 pcs
F	Magnetic catcher 	3 pcs
G	Wood Screws M4x15mm 	56 pcs
H	Wood Screws M3.5x20mm 	22 pcs
I	Plastic Wedges 	12 pcs
J	Shelf Pin 9mm 	8 pcs
K	Middle Door Hinge 	2 pcs
L	Side Door Hinge 	4 pcs
M	Support Arm 	1 pc
N	Anti-Tipping Kit 	2 pcs

720375-26 TV CONSOLE

1





Please do not tighten the bolts until all the bolts are lined with holes



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE



2



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


3



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


4



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


5



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


6



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720475-26 TV CONSOLE


7



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


8



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


9



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE

10





If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE

11

First install hinges with 2 screws in oval holes for door adjustment






If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


12

**Install other 2 screws
after doors are adjusted**



10







9



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

13

Our high Quality Euro hinges are 3-way adjustable:




If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.


Scan the code to watch the instructional video of door adjustment

14


Our high Quality Euro hinges are 3-way adjustable:



Lateral Adjustment



Horizontal Adjustment







Vertical Adjustment

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE

15



 G Screws M4x15mm 10pcs	 K Middle Door Hinge 2 pcs	 M Support Arm 1 pc
---	--	---



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


16



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

17

Setting the tension by adjusting the scew with the Allen wrench



Turn it clockwise to increase the tension, counterclockwise to decrease the tension when opening the Center Door

Don't use lubricant





If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

Scan the code to watch the instructional video


720375-26 TV CONSOLE

18




If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

19



Adjustable Floor Leveler

Compare the gap between the Side Door and the Top Panel , if the gap on one side is larger, it means that side is lower than the other side





Rotate counterclockwise to increase the length of Floor Leveler, and raise that corner. Rotate clockwise to lower that corner

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

20

Adjustable Magnetic catcher




Rotate counterclockwise to increase the length of Magnetic catcher, rotate clockwise to shorten the catcher

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

21


Anti-Tip Measures



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE


22



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

720375-26 TV CONSOLE

22



If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.